

Discontinuation of FFAST LT-200 USB Pen

August 2020

To provide improved accessibility to product configuration software and product based documents, the contents of the USB pen traditionally supplied with FFAST LT-200 shall now be available from the System Sensor website with immediate effect.

To download the contents, go to www.systemsensoreurope.com.

1. Select Resources → Software → FFAST Pipe IQ Software Setup
2. Select Resources → Product Manuals → FFAST LT-200 Advanced Setup and Control Guide
3. Select Resources → Product Manuals → FFAST LT-200 Setup and Trouble-shooting Guide

For customers whom have orders in process for FFAST LT-200 and require a USB pen; please contact offering management team, Vince Koh (Vince.Koh@honeywell.com) for further information.